

Instructions for Use

Board Trolley



Dear Customer!

Thank you for choosing a STARKE ARVID® product. We have more than 25 years of experience within the construction business. We develop, manufacture and sell equipment intended for professional material management. Starke Arvid´s product assortment includes a total of 20 different products. Browse in at www.starkearvid.se

Starke Arvid Board Trolley

The Starke Arvid Board Trolley is a plasterboard/sheet material transporter.

Because of its width the Board Trolley provides excellent manoeuvrability for limited loads of plasterboard or other sheet materials, even through narrow door openings.

The Board Trolley is supplied with two swivel casters, one with brake and also two large fixed wheels.

We would recommend that the fixed wheels are used at the lead end of the Board Trolley when the trolley is loaded to prevent undue damage to the swivel castors.

The removable vertical support bars must always be fully secured when in use.

The Starke Arvid Board Trolley is designed for internal use on flat and level surfaces only.

Starke Arvid would recommend that when transporting boards using the Board Trolley it should be carried out as a two man operation, with one at the front and one at the back of the trolley.

The Board Trolley should only be pushed on the line of the board and at no time should any force be exerted across or at an angle to the width of the trolley. Starke Arvid would also recommend that the Board Trolley is used to transport no more than 12no 2400x1200x12.5mm standard wallboards or the equivalent weight in other types of plasterboard/sheet materials

Local site conditions may require fewer boards are carried and this should be determined by a risk assessment before work starts.

The Starke Arvid Board Trolley has been designed specifically to carry plasterboard/ sheet materials as recommended in our notes but its actual use on site is beyond our control.

It is very important that worn or damaged wheels are replaced immediately before further use of the Board Trolley. Also we recommend that assessments are carried out regularly and that any worn or damaged parts within the Board Trolley are to be replaced/repaired immediately.

Health and Safety

Customers are also reminded that under the Health and Safety at Work Act 1974 and the following subsequent regulations, Management of Health and Safety at Work Regulations 1999, the provision and Use of Work Equipment Regulations 1999 and the Personal Protection Equipment Regulations 1992, that the employers are under a duty to ensure that all risks associated with the use of equipment are properly assessed, that employees are informed of such and where applicable are instructed, trained and supervised in the proper use of such equipment and protective equipment. The extent of instruction, training and supervision required will depend on the employees existing competence necessary to use the work equipment with due regard for Health and Safety.

Technical Data

Board Trolley

Width:	640 mm
Length:	1130 mm
Heigth:	1180 mm
Weight:	50 kg

Produced by:

Starke Arvid AB

Lyckåsvägen 3 SE-459 30 LJUNGSKILE

Phone: +46-(0)522 22 000 Fax: +46-(0)522 22 344

office@starkearvid.se www.starkearvid.se

Marketed by:

Starke Arvid Ltd.

Unit 11 Hayhill Industrial Estate

Sileby Road

Barrow Upon Soar Leicestershire LE12 8LD Fax: 0845-862 34 55

Phone: 01509-812 386

orders@starkearvid.co.uk www.starkearvid.co.uk